



Simple Maintenance Tips to Keep Your Floor Looking Like New

Daily Maintenance

Dust Mopping: This should be done at least once or twice a day when the floor is in use to remove dirt that gets tracked onto the floor that may grind away at the finish.

When dust mopping never use a freshly treated dust mop. This can leave the floor streaked, unattractive, and possibly slippery. Treat your mop with Hillyard Super Hil-Tone the night before it is to be used, hang it up, and use it the following day.

Weekly Maintenance

Damp Mopping: This should be done on a weekly basis in order to keep your floor looking new and to extend the life of the finish.

- 1. After placing wet floor signs, mix Hillyard Clean Scrub at a rate of ounces per gallon of water in a mop bucket.
- 2. Using a clean rayon mop, damp mop the entire floor and allow to dry.
- 3. If an automatic scrubber is available, take advantage of this labor saver. Mix Hillyard Clean Scrub at three ounces per gallon of water in the solution tank. (Use blue pads under the auto scrubber to scrub entire floor.)

Floor Restorative

The Hillyard Salvation Stripper should be done once or twice a year (depending upon usage of your floor) - This is a very aggressive cleaner, it is used to strip seal coats. Use to clean very dirty floors and remove black shoe marks off floor.

Continued Care

Protect floor against punctures by using furniture rests. All tables and chairs should have rubber feet or stoppers. Prevent heavy, sharp objects from being dropped or being pressed into the surface.

Instructions apply to regular daily use of floor.